


Break-Away™ Bike

Packing Instructions


Break  Away

RITCHEY




STEP 1

Place rear wheel cassette side down without quick release.



STEP 2


Place front wheel slightly offset on top of rear wheel without quick release.



STEP 3


Place protector mat on top. Tie/connect straps.

RITCHEY




STEP 4

Place rear triangle as shown. Remove left side pedal or crank.



STEP 5


Place front triangle as shown with down tube feeding through rear stays.



STEP 6


Place bars as shown.

RITCHEY




STEP 7

Place saddle and misc parts/shoes as shown. NOTE: To reduce chances of scratching paint use additional padding or packing material.



STEP 8

Connect straps as shown - secure tightly.



STEP 9

Finally zip and strap. Done!